

INSTALLATION INSTRUCTIONS

APPLY RETAINING COMPOUND (LOCTITE 609 P.N: 60905) TO TUBE NUT THREADS. TORQUE TO 25 ft. lbs.

180
140
100
60
20

Threaded Tube Nut Provided in Kit

Threaded Shaft of customers shock

Customer Spring Seat

Customer Spring

Customer Shock

Spacer Provided in Kit

THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF MSI/Moore-Sport INC.. ANY REPRODUCTION IN PART OR AS A WHOLE IS STRICTLY PROHIBITED.

Standard m10x1.25 Installation



CAR MODEL

Subaru BRZ/BRZ

CONFIGURATION:

ASSEMBLY:

REV

01/09/2016

APPLICATION

Street

As installed

MSIsub02-20-001

3

SHEET 2 OF 2

260 220 180 140 100 60 20